

Signal Tracer

Product Code:GE494



The SIGNAL TRACER is a solid square wave tracer. It test two signals

1. Modulated R.F. input for trouble shooting in TV receivers
2. Square wave audio input For troubleshooting in Radio receivers and Audio equipments. Input level of the instrument is variable.

The modulated R.F signal can be used for tracing faults in the VHF (TUNER) stages, LF. picture stages and I.F sound stages of TV receivers and in the HF and IF section of FM receivers. The AF square wave signal can be used to locate and tracing in Audio amplifiers of PA or music systems. AF amplifier stages of Radio and TV receivers.

TECHNICAL SPECIFICATIONS

CURRENT DRAIN	50 to 60 mAmp
INPUT SIGNAL A.F	400Hz Nominal
INPUT SIGNAL R.F	5.5 MHz (Nominal modulated)
Power Supply	220volts/50Hz,+ -10%
Accessory	Connecting lead with manual